


2 NOT USED  
SCALE: NO SCALE



- NOTES:
1. WIRE TO NEAREST PANEL WITH SPARE SPACE. UTILIZE 120V, 20A SINGLE POLE CIRCUIT BREAKER. PROVIDE HANDLE LOCK ON CIRCUIT BREAKER AND LABEL IN RED "FIRE ALARM SYSTEM" NEXT TO CIRCUIT BREAKER AND IN THE PANEL DIRECTORY.
  2. FAPS (FIRE ALARM POWER SUPPLY) ARE NOT SHOWN ON THE FLOOR PLANS. PROVIDE THE NUMBER OF FAPS UNITS REQUIRED TO SERVE APPLIANCES SHOWN PLUS SPARE CAPACITY AS SPECIFIED.
  3. VERIFY LOCATION AND QUANTITY OF ALL SMOKE DAMPERS WITH THE MECHANICAL DUCTWORK DRAWINGS. SEE THE DUCTWORK DRAWINGS TO ASSOCIATE THE SMOKE DAMPERS WITH EACH AIR HANDLING UNIT FOR GROUPING. SMOKE DAMPERS SHALL BE CONTROLLED AS A GROUP PER AIR HANDLING UNIT SERVED.
  4. THE SHUTDOWN OF HVAC EQUIPMENT AND CLOSING OF ALL SMOKE DAMPERS SHALL BE DONE VIA A SYSTEM U.L. LISTED FOR THIS TASK. COORDINATE WITH DIVISION 23 (MECHANICAL).

3 FIRE ALARM SYSTEM DETAILS AND NOTES  
SCALE: NO SCALE

1 NOT USED  
SCALE: NO SCALE




HARTT  
TRANSPORTATION

Auburn, ME  
Harriman Project No. 14507  
Key Plan Proj North



Issues and Revisions		
Mark	Date	Description
--	01-14-15	FOR CONSTRUCTION



Drawing Scales	
PA / PE: JWT	© 2015
Drawn By: JMB	Harriman Associates

DETAILS

E70.2